



ASSEMBLY INSTRUCTIONS DENMARK DESK

Please read instructions carefully. Remove all wrapping material, staples and packing straps from the carton. See hardware and furniture parts list for guidance. Be sure you have all parts before you start assembling. Place all wooden furniture parts on a clean, flat, soft surface; such as a carpet or rug to prevent the item from being scratched.




PARTS INCLUDED

1. Top	: 1pc
2. Leg	: 1pc
3. Cabinet	: 1pc
4. Bottom leg	: 1pc
5. Post	: 4pcs



HARDWARE LIST

A. Short bolt	: 4pcs
B. Long bolt	: 9pcs
C. Spring washer	: 9pcs
D. Washer	: 9pcs
E. Allen key	: 1pc





ASSEMBLY INSTRUCTIONS



DENMARK DESK

adairs



STEP 1



STEP 2



STEP 3





ASSEMBLY INSTRUCTIONS


DENMARK DESK

adairs

STEP 4



STEP 5



STEP 6

Please note stoppers on base of feet can be tightened or loosened for placement on uneven surfaces.

